MANUFACTURER DOCUMENT PACKAGE

Manufacturer's Manual

Reference package for procurement and maintenance review

EMERSON

KC4011X1-BD1 12P6758X022

REDUNDANT 16-CHANNEL AO TERMINAL BLOCK

Used with the applicable DeltaV redundant AO configuration.

REFERENCE PACKAGE

OFFICIAL DOCUMENT

Selected official manufacturer pages follow this cover.

Source: Emerson KC4011X1-BD1 ATEX159, July 2021

ATEX Instruction Sheet
Part Number: ATEX159
Publication date: July 2021

KC4011X1-BD1 Redundant AO 16-Channel Terminal Block

Hazardous Atmosphere

II 3G Ex ec nC IIC Gc
FM19ATEX0173U
IECEx FMG 19.0019U
FM21UKEX0017U

CL. I Div. 2 GP. A,B,C,D
CL. I Zone 2 AEx/Ex ec nC IIC Gc
FM17US0286U
FM17CA0145U

Power Specifications

Field Circuit	30 VDC at 100 mA/Channel

Environmental Specifications

Ambient Temperature	-40 °C to +70 °C
Shock	10 g half-sine wave for 11 ms
Vibration	1 mm peak to peak from 2 to 13.2 Hz; 0.7 g from 13.2 to 150 Hz
Airborne Contaminants	ISA-S71.04 –1985 Airborne Contaminants Class G3
Relative Humidity	5 to 95% Non-Condensing
Terminal block key position	A5

Note: Refer to the product label for serial number and location and date of manufacture.

Warning: This product has specific instructions for installation, removal and operation in hazardous areas. Refer to document 12P2046 *"DeltaV™ Scalable Process System Zone 2 Installation Instructions".* Other installation instructions are available in the *"DeltaV™ S-series and CHARMs Hardware Installation"* manual.

Removal and Insertion

Terminals Block can be added or removed with System Power applied only when no I/O Card is installed, and no field wiring is connected to the terminal.

A rotary keying system ensures compatibility between I/O cards and terminal blocks after installation is complete. The terminal block must have the keys set for the I/O card with which it is to be used.

Maintenance and Adjustment

This unit contains no user serviceable parts and should not be disassembled for any reason. Calibration is not required.

Other Safety Approvals

LR87534