

Ordering Information



For the detailed listing of country and product-specific approvals, refer to the [Approvals Quick Reference Guide \(108M1756\)](#).

For additional technical documentation, please log in to bntechsupport.com and access the Bently Nevada Media Library.

3500/04-AA-BB

A: I/O Module type: Earthing module

01	Earthing I/O Module
----	---------------------

B: Agency Approval

00	None
01	North American Hazloc
02	Multi (CSA, ATEX, IECEx)

When ordering internal barriers, specify the appropriate I/O module type for each monitor module.



Install an IS Earthing Module in each rack containing internal barriers.

Refer to each monitor module's datasheet for specifications and ordering information.

Spares

136719-01	Earthing I/O Module
138257-01	Earthing Module Front Panel
135473-01	3500/25 I/O Module with Internal Barriers and Internal Terminations
135489-01	3500/42, /70, /72 I/O Module with Internal Barriers (4 prox/accel channels) and Internal Terminations

135489-02	3500/42, /70 I/O Module with Internal Barriers (2 prox/accel + 2 Velomitor channels) and Internal Terminations
135489-03	3500/42, /70 I/O Module with Internal Barriers (4 Velomitor channels) and Internal Terminations
135489-04	3500/40 I/O Module with Internal Barriers and Internal Terminations
136703-01	3500/50 I/O Module with Internal Barriers and Internal Terminations
136711-01	3500/60 I/O Module with Internal Barriers and Internal Terminations
136711-02	3500/61 I/O Module with Internal Barriers and Internal Terminations
137110-01	3500/62 I/O Module with Internal Barriers and Internal Terminations