


FIELD INSTALLATION QUICK GUIDE

Installation Instructions

7400209-010 AO2481

Analog output baseplate



PRODUCT	7400209-010 AO2481
FAMILY	Triconex safety system
FUNCTION	Analog output baseplate
STATUS	Verify exact installed equipment

Prepared by Amikon Limited from Triconex documentation. This guide supplements the complete manufacturer manual and site procedure.

01

CONFIRM THE ORDERED CONFIGURATION

Component Type	Analog output baseplate
Assembly Number	7400209-010
Baseplate Model	2481
Compatible Module	Trident 3481 AO module
Channel Capacity	4 analogue outputs
Signal Service	4 to 20 mA current loops


02

PREPARATION AND CONNECTION

- Confirm the complete 7400209-010 AO2481 article number and installed revision.
- Isolate applicable electrical and process energy using the approved site procedure.
- Record every connector, cable, terminal, shield and protective-earth connection before removal.
- Install without forcing keyed parts, then secure terminals, latches, fasteners and cable supports.

78 Input/Output Modules

Model 2481 Analog Output Baseplate Field Connections



04 COMMISSIONING CHECKS

- 01 Confirm product identity and mechanical seating.
- 02 Verify the documented supply before energising.
- 03 Inspect polarity, shielding and protective-earth connections.
- 04 Restore power in the approved sequence and observe status indications.
- 05 Test each connected input, output or communication path.
- 06 Record diagnostics and functional-test results before return to service.

05 CONTROLLED DOCUMENT

Official source	Trident Planning Installation Guide
Product record	7400209-010 AO2481
Manufacturer	Triconex
Warranty	12 months from AMIKON
Support	INFO@AMIKON.CN

AMIKON PRODUCT SUPPORT

+86-18020776786

INFO@AMIKON.CN

AMIKONG.COM