

FIELD INSTALLATION QUICK GUIDE

Installation Instructions

3000290-380

External termination backplate

[illegible]

PRODUCT	3000290-380
FAMILY	Triconex safety system
FUNCTION	External termination backplate
STATUS	Verify exact installed equipment

Prepared by Amikon Limited from Triconex documentation. This guide supplements the complete manufacturer manual and site procedure.

01

CONFIRM THE ORDERED CONFIGURATION

Component Type	External termination backplate
Order Reference	3000290-380
System Platform	Triconex safety control system
Primary Function	Mounts external termination circuitry
Circuit Capacity	One termination-panel assembly
Nominal Supply	Passive field interface

02

PREPARATION AND CONNECTION

- Confirm the complete 3000290-380 article number and installed revision.
- Isolate applicable electrical and process energy using the approved site procedure.
- Record every connector, cable, terminal, shield and protective-earth connection before removal.
- Install without forcing keyed parts, then secure terminals, latches, fasteners and cable supports.

Part Number Cross-Reference

Part Number Cross-Reference—ETPs (continued)

Base Model #	ETA	FT4 Cable	Z Cable	LSZH Cable	FT1 Cable (Old)
9661-610	3000520-160	4000188-110	4000193-110	4000141-110	4000094-110
9661-810	3000550-180	4000188-110	4000193-110	4000141-110	4000094-110
9661-910	3000520-180	4000188-110	4000193-110	4000141-110	4000094-110
9662-110	3000570-310	4000188-310	4000193-310	4000141-310	4000094-310
9662-610	3000520-390	4000188-310	4000193-310	4000141-310	4000094-310
9662-710	3000550-390	4000188-310	4000193-310	4000141-310	4000094-310
9662-810	3000520-380	4000188-310	4000193-310	4000141-310	4000094-310
9662-910	3000550-380	4000188-310	4000193-310	4000141-310	4000094-310
9663-610	3000725-160	4000188-110	4000193-110	4000141-110	4000094-110
9664-110	3000726-110	4000188-110	4000193-110	4000141-110	4000094-110
9664-810	3000520-170	4000188-110	4000193-110	4000141-110	4000094-110
9667-110	3000570-710	4000188-210	4000193-210	4000141-210	4000094-210
9667-810	3000520-280	4000188-210	4000193-210	4000141-210	4000094-210
9667-910	3000550-280	4000188-210	4000193-210	4000141-210	4000094-210
9668-110	3000590-110	4000188-110	4000193-110	4000141-110	4000094-110
9670-110	3000290-110	4000203-110	4000204-110	n/a	4000111-110
9670-610	3000290-160	4000203-110	4000204-110	n/a	4000111-110
9671-610	3000769-390	4000196-310	4000200-310	n/a	4000166-310
9671-810	3000290-380	4000203-310	4000204-310	n/a	4000111-310
9672-810	3000290-280	4000203-210	4000204-210	n/a	4000111-210
9673-810	3000290-181	4000203-110	4000204-110	n/a	4000111-110
9750-210	3000420-120	4000206-510	4000207-510	n/a	4000093-510
9750-310	3000420-310	4000187-310	4000192-310	4000140-310	4000093-310
9750-410	3000420-410	4000187-210	4000192-210	4000140-210	4000093-210
9750-810	3000420-180	4000206-510	4000207-510	n/a	4000093-510
9753-110	3000400-510	4000189-510	4000191-510	4000142-510	4000103-510
9760-210	3000470-510	4000206-510	4000207-510	n/a	4000093-510
9760-410	3000470-530	4000206-510	4000207-510	n/a	4000093-510
9761-210	3000510-510	4000189-510	4000191-510	4000142-510	4000103-510
9761-410	3000510-530	4000189-510	4000191-510	4000142-510	4000103-510
9762-210	3000510-560	4000189-510	4000191-510	4000142-510	4000103-510

04 COMMISSIONING CHECKS

- 01 Confirm product identity and mechanical seating.
- 02 Verify the documented supply before energising.
- 03 Inspect polarity, shielding and protective-earth connections.
- 04 Restore power in the approved sequence and observe status indications.
- 05 Test each connected input, output or communication path.
- 06 Record diagnostics and functional-test results before return to service.

05 CONTROLLED DOCUMENT

Official source	Tricon Technical Product Guide
Product record	3000290-380
Manufacturer	Triconex
Warranty	12 months from AMIKON
Support	INFO@AMIKON.CN

AMIKON PRODUCT SUPPORT

+86-18020776786

INFO@AMIKON.CN

AMIKONG.COM