

AMIKON TECHNICAL DOCUMENTATION

Installation Instructions

MVI56-DFCM

ProSoft DF1 communication module

01 PRODUCT IDENTIFICATION

Manufacturer	ProSoft
Exact model	MVI56-DFCM
Product family	ControlLogix in-chassis modules
Component class	DF1 communication module
Primary function	DF1 half/full duplex protocol

02 CONFIRM THE ORDERED CONFIGURATION

Signal or Power Path	ControlLogix backplane data exchange
System Interface	Single-slot in-chassis module
Mounting Arrangement	RS-232/422/485 connectivity
Configuration Reference	Ladder logic data transfer
Replacement Control	Record wiring and companion hardware
Commissioning Check	Verify port polling and processor data

03 PREPARATION AND SAFETY

Only qualified personnel should install MVI56-DFCM. Isolate every applicable energy source, prove a safe state, use ESD protection where required, and retain the controlled ProSoft instructions at the work location.

04

MODEL-SPECIFIC INSTALLATION WORKFLOW

1

VERIFY

Confirm the complete MVI56-DFCM identity and ControlLogix in-chassis modules application.

2

DOCUMENT

Record ladder logic data transfer, adjacent hardware, labels and connections.

3

ISOLATE

Apply site lockout, discharge, absence-of-voltage and ESD controls appropriate to the equipment.

4

REMOVE

Support the DF1 communication module; release fasteners and connectors without forcing or distorting the assembly.

5

COMPARE

Match ControlLogix backplane data exchange, interfaces, mechanical design and companion hardware.

6

INSTALL

Seat and retain the replacement evenly; restore documented wiring, shields, earth paths or mechanical covers.

7

COMMISSION

Verify port polling and processor data

MANUFACTURER DOCUMENT APPLICABILITY

The appended ProSoft manufacturer documentation provides the product-family identity, configuration, connection or service information used for this installation reference. Apply only the sections that match the exact installed hardware.

05 PRE-ENERGIZATION AND HANDOVER CHECKLIST

Identity	Exact MVI56-DFCM and manufacturer markings confirmed
Mechanical	Ladder logic data transfer correctly seated and retained
Connections	RS-232/422/485 connectivity and documented interfaces restored
Configuration	Record wiring and companion hardware reviewed against the approved record
Functional test	Verify port polling and processor data
Documentation	Photos, settings, test results and replaced-part identity retained

06 CONTROLLED DOCUMENTS

PROSOFT MANUFACTURER DOCUMENTATION

Source: <https://www.amikong.com/Prosoft-c210.html>. Use the manufacturer manual and the site-controlled drawings for terminal functions, torque values, firmware or software conditions, safety limits and final acceptance criteria.

DO NOT INFER UNDOCUMENTED VALUES

Do not infer compatibility, electrical ratings, terminal functions, replacement status or configuration from appearance or a partial model number.

AMIKON PRODUCT SUPPORT

Amikon Limited +86-18020776786 INFO@AMIKON.CN AMIKONG.COM