

MANUFACTURER DOCUMENT PACKAGE

Manufacturer's Manual

Reference package for procurement and maintenance review

3500 SYSTEM

3500/42

MACHINERY MONITORING MODULE

Used with the applicable 3500 System configuration.

REFERENCE PACKAGE


OFFICIAL DOCUMENT

Selected official manufacturer pages follow this cover.

Source: Bently Nevada 3500/42 manufacturer documentation

Operation and Maintenance Manual

Bently Nevada™ Asset Condition Monitoring



3500/42 Proximitors/Seismic Monitor Module



imagination at work

Part Number 129773-01
Rev: H (07/07)

Copyright © 1995 Bently Nevada LLC
All rights reserved.

The information contained in this document is subject to change without notice.

The following are trademarks of General Electric Company in the United States and other countries:

Bently Nevada, Keyphasor and Proximito

Contact Information

The following ways of contacting Bently Nevada are provided for those times when you cannot contact your local representative:

Mailing Address	1631 Bently Parkway South Minden, Nevada USA 89423 USA
Telephone	1.775.782.3611 1.800.227.5514
Fax	1.775.215.2873
Internet	www.ge-energy.com/bently