

MANUFACTURER DOCUMENT PACKAGE

Manufacturer's Manual

SIEMENS SIMATIC S7

6ES7634-2BF02-0AE3

C7-634 DP COMPACT CONTROLLER

Applicable product family: SIMATIC C7 control systems

OFFICIAL SOURCE

6ES7634-2BF02-0AE3_official.pdf

The following pages are selected from the supplied manufacturer document and retain their original page content.

CPU	Order Number
SIMATIC S7-1500 CPUs	
CPU 1518-4 PN/DP	6ES7518-4AP00-0AB0
CPU 1518-3 PN	6ES7518-3AT10-0AB0
CPU 1518F-4 PN/DP	6ES7518-4FP00-0AB0
CPU 1518F-3 PN	6ES7518-3FT10-0AB0
CPU 1518T-4 PN/DP	6ES7518-4TP00-0AB0
CPU 1518T-3 PN	6ES7518-3TT10-0AB0
CPU 1518TF-4 PN/DP	6ES7518-4UP00-0AB0
CPU 1518TF-3 PN	6ES7518-3UT10-0AB0
CPU 1518-4 PN/DP ODK	6ES7518-4AP00-3AB0
CPU 1518F-4 PN/DP ODK	6ES7518-4FP00-3AB0
CPU 1518-4 PN/DP MFP	6ES7518-4AX00-1AC0
CPU 1518-4F PN/DP MFP	6ES7518-4FX00-1AC0
CPU 1517-3 PN/DP	6ES7517-3AP00-0AB0
CPU 1517-3 PN	6ES7517-3AQ10-0AB0
CPU 1517F-3 PN/DP	6ES7517-3FP00-0AB0
CPU 1517F-3 PN	6ES7517-3FQ10-0AB0
CPU 1517TF-3 PN/DP	6ES7517-3UP00-0AB0
CPU 1517TF-3 PN	6ES7517-3UQ10-0AB0
CPU 1517T-3 PN/DP	6ES7517-3TP00-0AB0
CPU 1517T-3 PN	6ES7517-3TQ10-0AB0
CPU 1516-3 PN/DP	6ES7516-3AN00-0AB0
	6ES7516-3AN01-0AB0
	6ES7516-3AN02-0AB0
	6ES7516-3AP03-0AB0
CPU 1516F-3 PN/DP	6ES7516-3FN00-0AB0
	6ES7516-3FN01-0AB0
	6ES7516-3FN02-0AB0
	6ES7516-3FP03-0AB0
CPU 1516TF-3 PN/DP	6ES7516-3UN00-0AB0
CPU 1516TF-3 PN	6ES7516-3UP10-0AB0
CPU 1516T-3 PN/DP	6ES7516-3TN00-0AB0
CPU 1516T-3 PN	6ES7516-3TP10-0AB0
CPU 1515-2 PN	6ES7515-2AM00-0AB0
	6ES7515-2AM01-0AB0
	6ES7515-2AM02-0AB0
	6ES7515-2AN03-0AB0
CPU 1515F-2 PN	6ES7515-2FM00-0AB0
	6ES7515-2FM01-0AB0
	6ES7515-2FM02-0AB0
	6ES7515-2FN03-0AB0
CPU 1515TF-2 PN	6ES7515-2UM01-0AB0
	6ES7515-2UN03-0AB0
CPU 1515T-2 PN	6ES7515-2TM01-0AB0
	6ES7515-2TN03-0AB0
CPU 1513-1 PN	6ES7513-1AL00-0AB0
	6ES7513-1AL01-0AB0
	6ES7513-1AL02-0AB0
	6ES7513-1AM03-0AB0
CPU 1513F-1 PN	6ES7513-1FL00-0AB0
	6ES7513-1FL01-0AB0
	6ES7513-1FL02-0AB0
	6ES7513-1FM03-0AB0

CPU	Order Number
SIMATIC S7-400 CPUs	
CPU 412-1	6ES7412-1XF03-0AB0
	6ES7412-1XF04-0AB0
	6ES7412-1XJ05-0AB0
	6ES7412-1XJ07-0AB0
CPU 412-2 DP	6ES7412-2XG00-0AB0
	6ES7412-2XG04-0AB0
	6ES7412-2XJ05-0AB0
	6ES7412-2XK07-0AB0
CPU 412-2 PN	6ES7412-2EK06-0AB0
	6ES7412-2EK07-0AB0
CPU 414-2 DP	6ES7414-2XG03-0AB0
	6ES7414-2XG04-0AB0
	6ES7414-2XK05-0AB0
	6ES7414-2XL07-0AB0
CPU 414-3 DP	6ES7414-3XJ00-0AB0
	6ES7414-3XJ04-0AB0
	6ES7414-3XM05-0AB0
	6ES7414-3XM07-0AB0
CPU 414-3 PN/DP	6ES7414-3EM05-0AB0
	6ES7414-3EM06-0AB0
	6ES7414-3EM07-0AB0
CPU 414F-3 PN/DP	6ES7414-3FM06-0AB0
	6ES7414-3FM07-0AB0
CPU 416-2 DP	6ES7416-2XK02-0AB0
	6ES7416-2XK04-0AB0
	6ES7416-2XN05-0AB0
	6ES7416-2XP07-0AB0
CPU 416F-2 DP	6ES7416-2FK02-0AB0
	6ES7416-2FK04-0AB0
	6ES7416-2FN05-0AB0
	6ES7416-2FP07-0AB0
CPU 416-3 DP	6ES7416-3XL00-0AB0
	6ES7416-3XL04-0AB0
	6ES7416-3XR05-0AB0
	6ES7416-3XS07-0AB0
	6ES7416-3ER05-0AB0
CPU 416-3 PN/DP	6ES7416-3ES06-0AB0
	6ES7416-3ES07-0AB0
	6ES7416-3FR05-0AB0
CPU 416F-3 PN/DP	6ES7416-3FS06-0AB0
	6ES7416-3FS07-0AB0
	6ES7416-3FR05-0AB0
CPU 417-4	6ES7417-4XL00-0AB0
	6ES7417-4XL04-0AB0
	6ES7417-4XT05-0AB0
	6ES7417-4XT07-0AB0
CPU 410 SMART	6ES7410-5HN08-0AB0
CPU 410E	6ES7410-5HM08-0AB0

CPU	Order Number
SIMATIC S7-400 H-CPU's	
CPU 412-3H	6ES7412-3HJ14-0AB0
CPU 414-4H	6ES7414-4HJ00-0AB0
	6ES7414-4HJ04-0AB0
	6ES7414-4HM14-0AB0
	6ES7417-4HL00-0AB0
CPU 417-4H	6ES7417-4HL01-0AB0
	6ES7417-4HL04-0AB0
	6ES7417-4HT14-0AB0
	6ES7412-5HK06-0AB0
CPU 412-5H	6ES7412-5HK06-0AB0
CPU 414-5H	6ES7414-5HM06-0AB0
CPU 416-5H	6ES7416-5HS06-0AB0
CPU 417-5H	6ES7417-5HT06-0AB0
SIMATIC PCS 7 CPU 410 Single AS with CPU 410-5H	6ES7654-5C...-....
	6ES7654-6C...-....
SIMATIC PCS 7 CPU 410 Redundancy AS with CPU 410-5H	6ES7656-5C...-....
	6ES7656-6C...-....
CPU 410-5H	6ES7410-5HX08-0AB0
SIMATIC M7	
CPU 388-4 ab V5.0	6ES7388-4BN00-0AC0
CPU 486-3 ab V5.0	6ES7486-3AA00-0AB0
CPU 488-3 ab V5.0	6ES7488-3AA00-0AB0
SIMATIC C7 Compact Units	
C7-626 P/DP	6ES7626-DG03-0AE3
	6ES7626-DG04-0AE3
C7-633 DP	6ES7633-2BF01-0AE3
	6ES7633-2BF02-0AE3
C7-634 DP	6ES7634-2BF01-0AE3
	6ES7634-2BF02-0AE3
C7-635 OP	6ES7635-2EC00-0AE3
	6ES7635-2EC01-0AE3
	6ES7635-2EC02-0AE3
C7-635 TB	6ES7635-2EB00-0AE3
	6ES7635-2EB01-0AE3
	6ES7635-2EB02-0AE3
C7-636 Key	6ES7636-2EC00-0AE3
C7-636 Touch	6ES7636-2EB00-0AE3

CPU	Order Number
SIMATIC Distributed Controller	
IM151-7 CPU	6ES7151-7AA10-0AB0
	6ES7151-7AA11-0AB0
	6ES7151-7AA13-0AB0
	6ES7151-7AA20-0AB0
	6ES7151-7AA21-0AB0
IM151-7F CPU	6ES7151-7FA00-0AB0
	6ES7151-7FA01-0AB0
	6ES7151-7FA20-0AB0
	6ES7151-7FA21-0AB0
IM151-8 PN/DP CPU	6ES7151-8AB00-0AB0
	6ES7151-8AB01-0AB0
IM151-8F PN/DP CPU	6ES7151-8FB00-0AB0
	6ES7151-8FB01-0AB0
IM154-8 PN/DP CPU	6ES7154-8AB01-0AB0
IM154-8F PN/DP CPU	6ES7154-8FB01-0AB0
IM154-8FX PN/DP CPU	6ES7154-8FX00-0AB0
CPU 1510SP-1 PN	6ES7510-1DJ00-0AB0
	6ES7510-1DJ01-0AB0
	6ES7510-1DK03-0AB0
CPU 1510SP F-1 PN	6ES7510-1SJ00-0AB0
	6ES7510-1SJ01-0AB0
	6ES7510-1SK03-0AB0
CPU 1512SP-1 PN	6ES7512-1DK00-0AB0
	6ES7512-1DK01-0AB0
	6ES7512-1DM03-0AB0
CPU 1512SP F-1 PN	6ES7512-1SK00-0AB0
	6ES7512-1SK01-0AB0
	6ES7512-1SM03-0AB0
CPU 1516PRO-2 PN	6ES7516-2PN00-0AB0
CPU 1516PRO F-2 PN	6ES7516-2GN00-0AB0