


FIELD INSTALLATION QUICK GUIDE

Installation Instructions

330130-080-01-00

8 m armored extension cable



PRODUCT	330130-080-01-00
FAMILY	3300 XL 8 mm Proximity Transducer System
FUNCTION	8 m armored extension cable
STATUS	Verify exact installed equipment

Prepared by Amikon Limited from Bently Nevada documentation. This guide supplements the complete manufacturer manual and site procedure.

01 CONFIRM THE ORDERED CONFIGURATION

Component Type	3300 XL standard extension cable
Cable Length	8.0 m (26.2 ft)
Cable Option	Armored cable
Agency Approval	Not required
Cable Construction	75 ohm triaxial, FEP insulated
Armor Material	AISI 302 or 304 stainless steel


02 PREPARATION AND CONNECTION

- Confirm the complete 330130-080-01-00 article number and installed revision.
- Isolate applicable electrical and process energy using the approved site procedure.
- Record every connector, cable, terminal, shield and protective-earth connection before removal.
- Install without forcing keyed parts, then secure terminals, latches, fasteners and cable supports.

OFFICIAL INSTALLATION REFERENCE

3300 XL 8 mm Proximity Transducer System
Datasheet

141194 Rev. AM



1. 7.24 mm (0.285 in) maximum diameter
2. Miniature male coaxial connector
3. FEP or PFA coated armor, armor length 300 mm (11.8 in) less than cable length (see Note 6)
4. 75Ω cable, 3.7 mm (0.15 in) maximum outside diameter, 3.94 mm (0.155 in) maximum diameter for FluidLoc cable, 7.67 mm (0.302 in) maximum outside diameter of armor, 10.2 mm (0.40 in) maximum diameter of armor ferrule
5. 7.24 mm (0.285 in) maximum diameter
6. Stainless steel ferrules, 10.2 mm (0.40 in) max diameter
7. FEP or PFA insulated triaxial cable
8. Miniature female coaxial connector
9. Cable length, +20%, -0%

Figure 17: Extension Cable without Connector Protectors

330130, 3300 XL Extension Cable (FEP Armor and Insulation)

330190, 3300 XL ETR Extension Cable (PFA Armor and Insulation)

04

COMMISSIONING CHECKS

- 01 Confirm product identity and mechanical seating.
- 02 Verify the documented supply before energising.
- 03 Inspect polarity, shielding and protective-earth connections.
- 04 Restore power in the approved sequence and observe status indications.
- 05 Test each connected input, output or communication path.
- 06 Record diagnostics and functional-test results before return to service.

05

CONTROLLED DOCUMENT

Official source	Bently Nevada 3300 XL 8 mm Proximity Transducer System Datasheet 141194 Rev. AM
Product record	330130-080-01-00
Manufacturer	Bently Nevada
Warranty	12 months from AMIKON
Support	INFO@AMIKON.CN

AMIKON PRODUCT SUPPORT

+86-18020776786

INFO@AMIKON.CN

AMIKONG.COM