

MANUFACTURER DOCUMENT PACKAGE

Manufacturer's Manual

Reference package for procurement and maintenance review

GE VERSAMAX

IC200CHS002L

BOX-STYLE I/O CARRIER

Used with the applicable VersaMax I/O carriers configuration.

REFERENCE PACKAGE

OFFICIAL DOCUMENT

Selected official manufacturer pages follow this cover.

Source: GE official manufacturer documentation



GE Fanuc Automation

Programmable Control Products

VersaMax® Modules, Power Supplies, and Carriers

User's Manual

GFK-1504K

March 2003

Warnings, Cautions, and Notes as Used in this Publication

Warning

Warning notices are used in this publication to emphasize that hazardous voltages, currents, temperatures, or other conditions that could cause personal injury exist in this equipment or may be associated with its use.

In situations where inattention could cause either personal injury or damage to equipment, a Warning notice is used.

Caution

Caution notices are used where equipment might be damaged if care is not taken.

Note

Notes merely call attention to information that is especially significant to understanding and operating the equipment.

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained herein does not purport to cover all details or variations in hardware or software, nor to provide for every possible contingency in connection with installation, operation, or maintenance. Features may be described herein which are not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of the information contained herein. No warranties of merchantability or fitness for purpose shall apply.

The following are trademarks of GE Fanuc Automation North America, Inc.

Alarm Master	Genius	PowerTRAC	Series Six
CIMPLICITY	Helpmate	ProLoop	Series Three
CIMPLICITY 90-ADS	Logicmaster	PROMACRO	VersaMax
CIMSTAR	Modelmaster	Series Five	VersaPoint
Field Control	Motion Mate	Series 90	VersaPro
GENet	PowerMotion	Series One	VuMaster
			Workmaster

Contents

Chapter 1	Introduction.....	1-1
	Getting Started	1-1
	The VersaMax [®] Family of Products	1-3
	CPU Modules for VersaMax PLCs	1-4
	Network Interface Units	1-6
	Power Supplies.....	1-8
	I/O Modules	1-9
	Carriers.....	1-13
	Expansion Modules	1-15
	Communications Modules.....	1-17
	VersaMax General Product Specifications.....	1-19
Chapter 2	Installation Instructions.....	2-1
	Preinstallation Check	2-1
	Conformance to Standards	2-2
	Thermal Considerations	2-2
	DIN Rail and Panel Mounting.....	2-3
	Installing an Expansion Transmitter Module	2-5
	Installing a Power Supply	2-9
	System Wiring Guidelines	2-11
	System Grounding.....	2-15
	Installing Wiring for I/O Devices.....	2-16
	Installing Modules.....	2-36
Chapter 3	Power Supplies	3-1
	IC200PWR001 24VDC Power Supply	3-2
	IC200PWR002 24VDC Expanded 3.3 V Power Supply.....	3-4
	IC200PWR101 120/240VAC Power Supply	3-6
	IC200PWR102 120/240VAC Expanded 3.3V Power Supply.....	3-8
	IC200PWR201 12VDC Power Supply	3-10
	IC200PWR202 12VDC Expanded 3.3 V Power Supply.....	3-12
Chapter 4	Carriers	4-1
	IC200CHS001 Barrier-Style I/O Carrier.....	4-2
	IC200CHS002 Box-Style I/O Carrier	4-5
	IC200CHS003 Connector-Style I/O Carrier	4-8
	IC200CHS005 Spring-Style I/O Carrier	4-11
	IC200CHS022 Compact Box-Style I/O Carrier	4-14
	IC200CHS025 Compact Spring-Style I/O Carrier	4-17
	IC200CHS006 Communications Carrier	4-20